## Pt. 60, App. A

overshoots since the significance of such overshoots becomes questionable. Only those overshoots larger than 5 per cent of the total initial displacement should be considered. The residual band, labeled T(Ad) on Figure A2A is ±5 percent of the initial displacement amplitude A<sub>d</sub> from the steady state value of the oscillation. Only oscillations outside the residual band are considered significant. When comparing FFS data to airplane data, the process should begin by overlaying or aligning the FFS and airplane steady state values and then comparing amplitudes of oscillation peaks, the time of the first zero crossing and individual periods of oscillation. The FFS should show the same number of significant overshoots to within one when compared against the airplane data. The procedure for evaluating the response is illustrated in Figure A2A.

(b) Critically damped and overdamped response. Due to the nature of critically damped and overdamped responses (no overshoots), the time to reach 90 percent of the steady state (neutral point) value should be the same as the airplane within ±10 percent. Figure A2B illustrates the procedure.

(c) Special considerations. Control systems that exhibit characteristics other than classical overdamped or underdamped responses should meet specified tolerances. In addition, special consideration should be given to ensure that significant trends are maintained.

(2) Tolerances.

m(D)

(a) The following table summarizes the tolerances, T, for underdamped systems, and "n" is the sequential period of a full cycle of oscillation. See Figure A2A of this attachment for an illustration of the referenced measurements.

1100/ - C T

$T(P_0)$	$\pm 10\%$ OI $P_0$ .
$T(P_1) \ \dots \dots$	$\pm 20\%$ of $P_1$ .
$T(P_2)$	$\pm 30\%$ of $P_2$ .
$T(P_n)$	$\pm 10(n + 1)\%$ of $P_n$ .
$T(A_n)\ \dots\dots$	$\pm 10\%$ of $A_1$ .
$T(A_d)$	$\pm 5\%$ of $A_d$ = residual
	band.

Significant overshoots, First overshoot and  $\pm 1$  subsequent overshoots.

(b) The following tolerance applies to critically damped and overdamped systems only. See Figure A2B for an illustration of the reference measurements:

 $T(P_0)$  ......  $\pm 10\%$  of  $P_0$  End Information

## BEGIN OPS REQUIREMENT

- c. Alternative method for control dynamics evaluation.
- (1) An alternative means for validating control dynamics for aircraft with hydraulically powered flight controls and artificial feel systems is by the measurement of control force and rate of movement. For each axis of pitch, roll, and yaw, the control must be forced to its maximum extreme position for the following distinct rates. These tests are conducted under normal flight and ground conditions.
- (a) Static test—Slowly move the control so that a full sweep is achieved within 95 to 105 seconds. A full sweep is defined as movement of the controller from neutral to the stop, usually aft or right stop, then to the opposite stop, then to the neutral position.
- (b) Slow dynamic test—Achieve a full sweep within 8--12 seconds.
- (c) Fast dynamic test—Achieve a full sweep within 3–5 seconds.

Note: Dynamic sweeps may be limited to forces not exceeding 100 lbs. (44.5 daN).

- (d) Tolerances
- (i) Static test; see Table A2A, FFS Objective Tests, Entries 2.a.1., 2.a.2., and 2.a.3.
- (ii) Dynamic test— $\pm 2$  lbs (0.9 daN) or  $\pm 10\%$  on dynamic increment above static test.

## END QPS REQUIREMENT

## BEGIN INFORMATION

d. The FAA is open to alternative means such as the one described above. The alternatives should be justified and appropriate to the application. For example, the method described here may not apply to all manufacturers' systems and certainly not to aircraft with reversible control systems. Each case is considered on its own merit on an ad hoc basis. If the FAA finds that alternative methods do not result in satisfactory performance, more conventionally accepted methods will have to be used.