Pilot/Controller Glossary 8/15/19

BROADCAST – Transmission of information for which an acknowledgement is not expected.

(See ICAO term BROADCAST.)

BROADCAST [ICAO] – A transmission of information relating to air navigation that is not addressed to a specific station or stations.

BUFFER AREA- As applied to an MVA or MIA chart, a depicted three (3) or five (5) NM radius MVA/MIA sector isolating a displayed obstacle for which the sector is established. A portion of a buffer area can also be inclusive of a MVA/MIA sector polygon boundary.