

TABLE D3E—TABLE OF FUNCTIONS AND SUBJECTIVE TESTS LEVEL 5 FTD—Continued

QPS requirements	
Entry No.	Operations tasks
4. Instrument Procedures	
4.a.	Coupled instrument approach maneuvers (as applicable for the systems installed).
5. Normal and Abnormal Procedures (any phase of flight)	
5.a.	Normal system operation (installed systems).
5.b.	Abnormal/Emergency system operation (installed systems).
6. Postflight Procedures	
6.a.	Parking and Securing.
6.b.	Engine and systems operation.
6.c.	Parking brake operation.
6.d.	Rotor brake operation.
6.e.	Abnormal/emergency procedures.
7. Instructor Operating Station (IOS), as appropriate	
7.a.	Power Switch(es).
7.b.	Preset positions (ground; air)
7.c.	Helicopter system malfunctions.
7.c.1.	Insertion/deletion.
7.c.2.	Problem clear.
7.d.	Control Loading System (as applicable) On/off/emergency stop.
7.e.	Observer Stations.
7.e.1.	Position.
7.e.2.	Adjustments.

TABLE D3F—TABLE OF FUNCTIONS AND SUBJECTIVE TESTS LEVEL 4 FTD

QPS requirements	
Entry No.	Operations tasks
Tasks in this table are subject to evaluation if appropriate for the helicopter simulated as indicated in the SOQ Configuration List or for a Level 4 FTD. Items not installed or not functional on the FTD and not appearing on the SOQ Configuration List, are not required to be listed as exceptions on the SOQ.	
1. Preflight Procedures	
1.a.	Preflight Inspection (Flight Deck Only) switches, indicators, systems, and equipment.
1.b.	APU/Engine start and run-up.
1.b.1.	Normal start procedures.
1.b.2.	Alternate start procedures.
1.b.3.	Abnormal starts and shutdowns.
2. Normal and Abnormal Procedures (any phase of flight)	
2.a.	Normal system operation (installed systems).
2.b.	Abnormal/Emergency system operation (installed systems).