## § 93.341

code while operating within the DC SFRA:

- (5) For VFR operations, the pilot must file and activate a DC FRZ or DC SFRA flight plan by obtaining a discrete transponder code. The flight plan is closed upon landing at an airport within the DC SFRA or when the aircraft exits the DC SFRA;
- (6) Before operating the aircraft into, out of, or through the Washington, DC Tri-Area Class B Airspace Area, the pilot receives a specific Air Traffic Control clearance to operate in the Class B airspace area; and
- (7) Before operating the aircraft into, out of, or through Class D airspace area that is within the DC SFRA, the pilot complies with §91.129 of this chapter
- (b) Paragraph (a)(5) of this section does not apply to operators of Department of Defense aircraft, law enforcement operations, or lifeguard or air ambulance operations under an FAA/TSA airspace authorization, if the flight crew is in contact with Air Traffic Control and is transmitting an Air Traffic Control-assigned discrete transponder code.
- (c) When operating an aircraft in the VFR traffic pattern at an airport within the DC SFRA (but not within the DC FRZ) that does not have an airport traffic control tower, a pilot must—
- (1) File a DC SFRA flight plan for traffic pattern work;
- (2) Communicate traffic pattern position via the published Common Traffic Advisory Frequency (CTAF);
- (3) Monitor VHF frequency 121.5 or UHF frequency 243.0, if the aircraft is suitably equipped;
- (4) Obtain and transmit the Air Traffic Control-assigned discrete transponder code; and
- (5) When exiting the VFR traffic pattern, comply with paragraphs (a)(1) through (a)(7) of this section.
- (d) When operating an aircraft in the VFR traffic pattern at an airport within the DC SFRA (but not within the DC FRZ) that has an operating airport traffic control tower, a pilot must—
- (1) Before departure or before entering the traffic pattern, request to remain in the traffic pattern;
- (2) Remain in two-way radio communications with the tower. If the air-

craft is suitably equipped, the pilot must also monitor VHF frequency 121.5 or UHF frequency 243.0:

- (3) Continuously operate the aircraft transponder on code 1234 unless Air Traffic Control assigns a different code; and
- (4) Before exiting the traffic pattern, comply with paragraphs (a)(1) through (a)(7) of this section.
- (e) Pilots must transmit the assigned transponder code. No pilot may use transponder code 1200 while in the DC SFRA.

## § 93.341 Aircraft operations in the DC FRZ.

- (a) Except as provided in paragraph (b) of this section, no pilot may conduct any flight operation under part 91, 101, 103, 105, 125, 133, 135, or 137 of this chapter in the DC FRZ, unless the specific flight is operating under an FAA/TSA authorization.
- (b) Department of Defense (DOD) operations, law enforcement operations, and lifeguard or air ambulance operations under an FAA/TSA airspace authorization are excepted from the prohibition in paragraph (a) of this section if the pilot is in contact with Air Traffic Control and operates the aircraft transponder on an Air Traffic Controlassigned beacon code.
- (c) The following aircraft operations are permitted in the DC FRZ:
- (1) Aircraft operations under the DCA Access Standard Security Program (DASSP) (49 CFR part 1562) with a Transportation Security Administration (TSA) flight authorization.
- (2) Law enforcement and other U.S. Federal aircraft operations with prior FAA approval.
- (3) Foreign-operated military and state aircraft operations with a State Department-authorized diplomatic clearance, with State Department notification to the FAA and TSA.
- (4) Federal, State, Federal DOD contract, local government agency aircraft operations and part 121, 129 or 135 air carrier flights with TSA-approved full aircraft operator standard security programs/procedures, if operating with DOD permission and notification to the FAA and the National Capital Regional Coordination Center (NCRCC). These flights may land and depart Andrews