

## § 135.411

landing weight limitations in the Approved Airplane Flight Manual or equivalent for operations under this part.

(b) No person may operate an airplane that is certificated under § 135.169(b)(6) unless that person complies with the landing limitations prescribed in §§ 135.385 and 135.387 of this part. For purposes of this paragraph, §§ 135.385 and 135.387 are applicable to reciprocating and turbopropeller-powered small airplanes notwithstanding their stated applicability to turbine engine powered large transport category airplanes.

[44 FR 53731, Sept. 17, 1979]

## Subpart J—Maintenance, Preventive Maintenance, and Alterations

### § 135.411 Applicability.

(a) This subpart prescribes rules in addition to those in other parts of this chapter for the maintenance, preventive maintenance, and alterations for each certificate holder as follows:

(1) Aircraft that are type certificated for a passenger seating configuration, excluding any pilot seat, of nine seats or less, shall be maintained under parts 91 and 43 of this chapter and §§ 135.415, 135.417, 135.421 and 135.422. An approved aircraft inspection program may be used under § 135.419.

(2) Aircraft that are type certificated for a passenger seating configuration, excluding any pilot seat, of ten seats or more, shall be maintained under a maintenance program in §§ 135.415, 135.417, 135.423 through 135.443.

(b) A certificate holder who is not otherwise required, may elect to maintain its aircraft under paragraph (a)(2) of this section.

(c) Single engine aircraft used in passenger-carrying IFR operations shall also be maintained in accordance with § 135.421 (c), (d), and (e).

(d) A certificate holder who elects to operate in accordance with § 135.364 must maintain its aircraft under paragraph (a)(2) of this section and the ad-

## 14 CFR Ch. I (1–1–19 Edition)

ditional requirements of Appendix G of this part.

[Doc. No. 16097, 43 FR 46783, Oct. 10, 1978, as amended by Amdt. 135–70, 62 FR 42374, Aug. 6, 1997; Amdt. 135–78, 65 FR 60556, Oct. 11, 2000; Amdt. 135–92, 68 FR 69308, Dec. 12, 2003; Amdt. 135–81, 70 FR 5533, Feb. 2, 2005; Amdt. 135–108, 72 FR 1885, Jan. 16, 2007; 72 FR 53114, Sept. 18, 2007]

### § 135.413 Responsibility for airworthiness.

(a) Each certificate holder is primarily responsible for the airworthiness of its aircraft, including airframes, aircraft engines, propellers, rotors, appliances, and parts, and shall have its aircraft maintained under this chapter, and shall have defects repaired between required maintenance under part 43 of this chapter.

(b) Each certificate holder who maintains its aircraft under § 135.411(a)(2) shall—

(1) Perform the maintenance, preventive maintenance, and alteration of its aircraft, including airframe, aircraft engines, propellers, rotors, appliances, emergency equipment and parts, under its manual and this chapter; or

(2) Make arrangements with another person for the performance of maintenance, preventive maintenance, or alteration. However, the certificate holder shall ensure that any maintenance, preventive maintenance, or alteration that is performed by another person is performed under the certificate holder's manual and this chapter.

### § 135.415 Service difficulty reports.

(a) Each certificate holder shall report the occurrence or detection of each failure, malfunction, or defect in an aircraft concerning—

(1) Fires during flight and whether the related fire-warning system functioned properly;

(2) Fires during flight not protected by related fire-warning system;

(3) False fire-warning during flight;

(4) An exhaust system that causes damage during flight to the engine, adjacent structure, equipment, or components;

(5) An aircraft component that causes accumulation or circulation of smoke, vapor, or toxic or noxious