

§ 1544.225

(c) Each Federal Air Marshal must be carried on a first priority basis and without charge while on duty, including positioning and repositioning flights. When a Federal Air Marshal is assigned to a scheduled flight that is canceled for any reason, the aircraft operator must carry that Federal Air Marshal without charge on another flight as designated by TSA.

(d) Each aircraft operator must assign the specific seat requested by a Federal Air Marshal who is on duty status. If another LEO is assigned to that seat or requests that seat, the aircraft operator must inform the Federal Air Marshal. The Federal Air Marshal will coordinate seat assignments with the other LEO.

(e) The Federal Air Marshal identifies himself or herself to the aircraft operator by presenting credentials that include a clear, full-face picture, the signature of the Federal Air Marshal, and the signature of the FAA Administrator. A badge, shield, or similar device may not be used or accepted as the sole means of identification.

(f) The requirements of § 1544.219(a) do not apply for a Federal Air Marshal on duty status.

(g) Each aircraft operator must restrict any information concerning the presence, seating, names, and purpose of Federal Air Marshals at any station or on any flight to those persons with an operational need to know.

(h) Law enforcement officers authorized to carry a weapon during a flight will be contacted directly by a Federal Air Marshal who is on that same flight.

§ 1544.225 Security of aircraft and facilities.

Each aircraft operator must use the procedures included, and the facilities and equipment described, in its security program to perform the following control functions with respect to each aircraft operation:

(a) Prevent unauthorized access to areas controlled by the aircraft operator under an exclusive area agreement in accordance with § 1542.111 of this chapter.

(b) Prevent unauthorized access to each aircraft.

(c) Conduct a security inspection of each aircraft before placing it into pas-

49 CFR Ch. XII (10–1–18 Edition)

senger operations if access has not been controlled in accordance with the aircraft operator security program and as otherwise required in the security program.

(d) When operating under a full program or a full all-cargo program, prevent unauthorized access to the operational area of the aircraft while loading or unloading cargo.

[67 FR 8364, Feb. 22, 2002, as amended at 71 FR 30510, May 26, 2006]

§ 1544.227 Exclusive area agreement.

(a) An aircraft operator that has entered into an exclusive area agreement with an airport operator, under § 1542.111 of this chapter must carry out that exclusive area agreement.

(b) The aircraft operator must list in its security program the locations at which it has entered into exclusive area agreements with an airport operator.

(c) The aircraft operator must provide the exclusive area agreement to TSA upon request.

(d) Any exclusive area agreements in effect on November 14, 2001, must meet the requirements of this section and § 1542.111 of this chapter no later than November 14, 2002.

§ 1544.228 Access to cargo and cargo screening: Security threat assessments for cargo personnel in the United States.

This section applies in the United States to each aircraft operator operating under a full program under § 1544.101(a) or a full all-cargo program under § 1544.101(h).

(a) Before an aircraft operator authorizes and before an individual performs a function described in paragraph (b) of this section—

(1) Each individual must successfully complete a security threat assessment or comparable security threat assessment described in part 1540 subpart C of this chapter; and

(2) Each aircraft operator must complete the requirements in part 1540 subpart C.

(b) The security threat assessment required in paragraph (a) of this section applies to the following:

(1) Each individual who has unescorted access to cargo and access