7–1–30. Key to Aerodrome Forecast (TAF) and Aviation Routine Weather Report (METAR)

FIG 7-1-21 Key to Aerodrome Forecast (TAF) and Aviation Routine Weather Report (METAR) (Front)



Key to Aerodrome Forecast (TAF) and Aviation Routine Weather Report (METAR) (Front)



$\mathbf{T} \mathbf{A} \mathbf{E}$ EVALUATE AND THE ADDALUT FOR A LODGER TO A LODGER TO ADDALUT FOR A DALUT FOR A DALU
TAF KPIT 091730Z 0918/1024 15005KT 5SM HZ FEW020 WS010/31022KT
FM091930 30015G25KT 3SM SHRA OVC015
TEMPO 0920/0922 1/2SM +TSRA OVC008CB
FM100100 27008KT 5SM SHRA BKN020 OVC040
PROB30 1004/1007 1SM -RA BR
FM101015 18005KT 6SM -SHRA OVC020
BECMG 1013/1015 P6SM NSW SKC
NOTE: Users are cautioned to confirm DATE and TIME of the TAF. For example FM100000 is
0000Z on the 10th. Do not confuse with 1000Z!
IETAR KPIT 091955Z COR 22015G25KT 3/4SM R28L/2600FT TSRA OVC010CB 18/16 A2992 RMK

SLP045 T01820159

Forecast	Explanation	Report
TAF	Message type: <u>TAF</u> -routine or <u>TAF AMD</u> -amended forecast, <u>METAR</u> -	METAR
	hourly, SPECI-special or TESTM-non-commissioned ASOS report	
KPIT	ICAO location indicator	KPIT
091730Z	Issuance time: ALL times in UTC "Z", 2-digit date, 4-digit time	091955Z
0918/1024	Valid period, either 24 hours or 30 hours. The first two digits of EACH	
	four digit number indicate the date of the valid period, the final two di-	
	gits indicate the time (valid from 18Z on the 9 th to 24Z on the 10 th).	
	In U.S. METAR: <u>COR</u> rected ob; or <u>AUTO</u> mated ob for automated re-	COR
	port with no human intervention; omitted when observer logs on.	
15005KT	Wind: 3 digit true-north direction, nearest 10 degrees (or <u>VaRiaBle</u>);	22015G25KT
	next 2-3 digits for speed and unit, KT (KMH or MPS); as needed, Gust	
	and maximum speed; 00000KT for calm; for METAR, if direction varies	
	60 degrees or more, <u>V</u> ariability appended, e.g., $180V260$	
5SM	Prevailing visibility; in U.S., Statute Miles & fractions; above 6 miles in	3⁄4SM
	TAF Plus6SM. (Or, 4-digit minimum visibility in meters and as re-	
	quired, lowest value with direction)	
	Runway Visual Range: <u>R</u> ; 2-digit runway designator <u>L</u> eft, <u>C</u> enter, or	R28L/2600FT
	<u>Right as needed; "/", Minus or Plus in U.S., 4-digit value, FeeT in U.S.,</u>	
	(usually meters elsewhere); 4-digit value <u>V</u> ariability 4-digit value (and	
	(usually indees ensewhere), $+$ and + and $+$ and $+$ and $+$ and $+$ and $+$	
HZ	Significant present, forecast and recent weather: see table (on back)	TSRA
FEW020	Cloud amount, height and type: <u>Sky Clear 0/8, FEW</u> $> 0/8-2/8$, <u>ScaT</u> tered	OVC 010CB
	3/8-4/8, BroKeN 5/8-7/8, OverCast 8/8; 3-digit height in hundreds of ft;	0,0,0,000
	Towering Cumulus or Cumulonim <u>B</u> us in METAR; in TAF, only CB.	
	<u>Vertical Visibility for obscured sky and height "VV004". More than 1</u>	
	layer may be reported or forecast. In automated METAR reports only,	
	<u>CleaR</u> for "clear below 12,000 feet"	
	Temperature: degrees Celsius; first 2 digits, temperature "/" last 2 digits,	18/16
		10/10
	dew-point temperature; <u>M</u> inus for below zero, e.g., M06 Altimeter setting: indicator and 4 digits; in U.S., <u>A</u> -inches and hun-	A2992
WS010/21022//T		A2992
	dredths; (Q-hectoPascals, e.g., Q1013)	
WS010/31022KT		
	height (hundreds of ft); "/"; 3-digit wind direction and 2-3 digit wind	
	speed above the indicated height, and unit, <u>KT</u>	